

Micellar 2-in-1 Conditioning Shampoo

Formula: HC1901-06

#	Phase	Trade Name	INCI Name	Function	% Wt./Wt.
1	B	Deionized Water	Aqua	Diluent	q.s.
2	A	TI-NatSurf®QCB	Aqua, Cocamidopropyl hydroxysultaine, Myristamine oxide, Capryl glucoside, Decyl glucoside	Functional Surfactant System	45.00
3	A	Zenigloss® Q	Polyquaternium-57	Conditioner/Glossing Agent	0.50
4	C	Stepan Mild®GCC	Glyceryl Caprylate/Caprate	Thickener	1.00
5	C	Salt	Sodium Chloride	Rheology Modifier	q.s.
6	C	Fragrance*	Parfum	Fragrance	q.s.
7	C	Color*	Color	Colorant	q.s.
8	---	Sodium Hydroxide (50% Solution)	Sodium Hydroxide	pH+ Adjuster	q.s.
9	---	Citric Acid (25% Solution)	Citric Acid	pH- Adjuster	q.s.

*The use of and levels of a fragrance and/or color are purely optional and at the customer's discretion.

Procedure

Phase A: (Creating the Concentrate)

1. Into a suitable mixing vessel charge the calculated amount of **#2**.
2. Slowly heat **#2** to 50 °C with moderate agitation.
3. While maintaining 50 °C, begin homogenization process to a speed of 1,200 RPM.
4. Add in **#3** in a slow continuous stream into the vortex.
5. Once completely incorporated, continue homogenization at 1,200 RPM for 3 minutes.
6. Increase speed to 2,200 RPM for an additional 2 minutes.
7. After homogenization, move solution back to high mixing, and heat to 50 °C for a further 15 to 20 minutes

Phase B: (The Dilution)

8. While maintaining moderate agitation and 50 °C, charge the calculated amount of **#1**.
9. Heat the solution to 80 °C and bring agitation/mixing to a high speed.

Phase C:

10. Discontinue heat and begin cooling process while maintain agitation.
11. When at 65 °C, add ingredient **#4**.
12. When at 40 °C, then add ingredients **#6 & #7** and mix until uniform.
13. Discontinue heating, and check Product specifications, and adjust accordingly‡.
14. Continue to cool to 23 °C.
15. Once cool, add in **#5** to the required viscosity.

Note: If solution is still not clear after cooling—reheat to 80 °C and mix until clear.

‡Adjust pH accordingly with either Citric Acid (25 % w/w solution) or Sodium Hydroxide (50% w/w solution).

Target Characterization:

Appearance @25°C Crystal Clear micro-emulsion
pH (10%) @ 25°C: 6.00 to 6.50
Salt Range: 3.00%-4.00%

Formula Courtesy of



The information above is provided in good faith, is believed to be accurate but without warranty, implied or expressed. All formulations are provided as a starting point for lab scale projects only and results may vary due to procedure, raw material, and equipment variations. Reproducibility and scale-up must be carried out and confirmed by the customer. Paradigm Science Inc. makes no warranty, expressed or implied that the suggested use infringes on any patent. Preservative recommendations are not provided.