

Super Shine Lip Gloss with SiBrid® PM-212 & SiBrid® TM-181

In lip products, SiBrid® PM-212 provides shine while ensuring comfortable wear. The addition of SiBrid® TM-181 gels the oil to suspend pigments while providing a rich and substantive feel.

INCI Name	Ingredient	Supplier	Wt%
Phase A			
Triisostearyl Citrate	Schercemol® TISC	Lubrizonl	q.s.
Laurylphenylpropyl Methicone	SiBrid® PM-212	Gelest/Paradigm Science	20.00
Stearyl Methicone	SiBrid® TM-181	Gelest/Paradigm Science	5.00
Preservatives			q.s.
Phase B			
Red 7 Lake/CI 15850 in			q.s.
Polydiethylsiloxane	SiBrid® DE-15	Gelest/Paradigm Science	q.s.
Phase C			
Mica (&) Titanium Dioxide (&) Silica (&) Stearyl Triethoxysilane	SS Treated Pearl	Gelest/EMD	0.50
Total			100.00

Procedure:

- Disperse Phase B using a roller mill.
- Combine Phase A and stir under propeller.
- Add Phase B and continue stirring until dispersed.
- Add Phase C and stir until dispersed and uniform.

Formula Courtesy of 
 Silicon Innovations for Cosmetics

The information above is provided in good faith, is believed to be accurate but without warranty, implied or expressed. All formulations are provided as a starting point for lab scale projects only and results may vary due to procedure, raw material, and equipment variations. Reproducibility and scale-up must be carried out and confirmed by the customer. Gelest, Inc. makes no warranty, expressed or implied that the suggested use infringes on any patent. Preservative recommendations are not provided.