



Lipstick with SiBrid[®] TM-081

Formula GCA1-19-3

In lipsticks, SiBrid[®] TM-081 helps to achieve a lighter, more comfortable feel in addition to creating initial slip and improving glide on application.

INCI Name	Ingredient	Supplier	Wt%
Phase A			
Pigment			7.50
Castor Oil	Crystal [®] O	Vertellus	7.50
Phase B			
Triisostearyl Citrate	Schercemol [®] TISC	Lubrizol	37.80
Octyldodecyl Stearate	Ceraphyl [®] ODS	Ashland/ISP	10.80
Euphoria Cerifera (Candelilla) Wax	Candelilla Wax	Frank B. Ross	7.60
Castor Oil	Crystal [®] O	Vertellus	6.70
Caprylyl Methicone	SiBrid[®] TM-081	Gelest	5.40
Microcrystalline Wax	Microcrystalline Wax SP19	Strahl & Pitsch	3.80
Ozokerite	Ozokerite 170D	Frank B. Ross	2.15
Antioxidants			q.s.
Preservatives			q.s.
Phase C			
Mica			8.00
Total			100.00

Procedure:

- Disperse Phase A using a roller mill.
- Combine Phase B and heat to 80°C. Once melted, slowly stir under propeller blade.
- Add Phase A and continue stirring for 45 minutes or until dispersed.
- Add Phase C and stir until dispersed and desired pouring temperature is reached.
- Pour into mold.

Rev 1 (03262013)

Contact us:
 Gelest, Inc.
 11 East Steel Road
 Morrisville, PA 19067
 USA
 215-547-1015
 www.gelest.com
 sales@gelest.com

US Distributors:
 Ross Organics (West Coast)
 Paradigm Science (East Coast)
 CA Specialities, LTD (South)

The information above is provided in good faith, is believed to be accurate but without warranty, implied or expressed. All formulations are provided as a starting point for lab scale projects only and results may vary due to procedure, raw material, and equipment variations. Reproducibility and scale-up must be carried out and confirmed by the customer. Gelest, Inc. makes no warranty, expressed or implied that the suggested use infringes on any patent. Preservative recommendations are not provided.